

Macintosh edition

Recommended system

Mac computer with an Intel processor running OS.

The following Mac operating systems are supported (as of April 2014) by this driver. Use of this driver with other operating systems cannot be guaranteed.

Mac OS X 10.6.4 or later (Snow Leopard)

OS X Lion 10.7

OS X Mountain Lion 10.8

OS X Mavericks 10.9

1. Double-click the pkg file to launch the installer.



License.rtf




Read_Me_First_(Install_Guide_m).pdf



TEAC USB HS Audio KEXT Install Package 273.4.2.pkg


- When using OS 10.8 (Mountain Lion), if Gatekeeper prevents the installer from launching, press the [control] key while clicking the installer or right-click the installer and select "Open" from the contextual menu.




Select "Open" when the following dialog box appears.





2. Click Continue.




3. Click Install to start installation. (You will need to enter an administrator password.)



Continued on the next page →




4. After installation completes, click Restart to restart the computer.



5. Follow steps 1–4 of “Playing Back Music Files Stored on a Computer” in the Owner’s Manual to make the computer automatically use the unit for audio output.

Open the Output page of the System Preferences Sound pane to select the audio output as shown below.



6. Follow step 5 of “Playing Back Music Files Stored on a Computer” in the Owner’s Manual to play a music file.

NOTE: You can set the output sampling frequency using the Audio MIDI Setup application, which is in the Utilities sub-folder of the Applications folder.

